

WINDOW FILM CLEANING INSTRUCTIONS

The following are washing and maintenance instructions for all your custom printed window films. Post these instructions where employees and/or maintenance personnel can read them since failure to follow them will irrevocably void your warranty.

DO NOT CLEAN UNTIL THIRTY (30) DAYS AFTER THE INSTALLATION DATE.

Recommended cleaner is soapy water and microfiber cloth.

DO NOT USE BRISTLE BRUSHES OR ANY OTHER MATERIAL THAT MIGHT SCRATCH THE SURFACE. CAUTION! DO NOT USE AMMONIA OR VINEGAR OR ANY PRODUCTS CONTAINING AMMONIA OR VINEGAR TO CLEAN THE FILM. Some paper towels are coarse enough to scratch the Film. Repeated use of improper cleaning implements and/or solutions will damage the appearance of the film.

GENERAL GUIDELINES

DO NOT USE ANY ADHESIVE TAPES, LABELS, OR SIGNAGE ON THE SURFACES TO WHICH THE FILM HAS BEEN APPLIED.

Under reasonable weather conditions, the film will dry flat, with no blisters, within 30 days, when viewed under normal viewing conditions. Normal viewing conditions are viewing treated windows from a distance of ten feet from the room side, at angles of up to 45 degrees, looking at a clear or uniformly overcast sky. Since a particle-free application is possible only under sterile conditions, there may be small amounts of dust or grit caught between the film and glass.

Please be advised that there may be a small amount of water left behind, particularly with the thicker films. Please be patient. Within approximately 60-90 days, this water will diffuse out through the film. However, in the event that you see larger blisters forming within 24 hours after the installation, please call your installation company immediately.

For help on specific questions please contact ClimatePro | VisualPro at 800-479-6292 or customercare@climatepro.com